



Redding Reloading Equipment Cortland, NY 13045

[www.redding-reloading.com](http://www.redding-reloading.com) [techline@redding-reloading.com](mailto:techline@redding-reloading.com) 607-753-3331

## Bullet Seating Micrometer Instructions

**Congratulations** on your purchase of the Redding Bullet Seating Micrometer. This precision micrometer directly replaces the seat plug in your current seating die and adds a higher level of precision and repeatability. Before you start, be sure you have the correct Bullet Seating Micrometer for your die set by comparing the number on the existing seat plug to the number on the micrometer.

### Instructions

- Mount your seating die in the press as normal.
- If you have previously used this die and have the body lock ring adjust for a proper crimp there is no need to reset that function.
- To replace your original seat plug, simply loosen the lock ring to remove it and install the replacement Bullet Seating Micrometer in its place.
- The knurled shoulder should be tightened securely against the die body.
- Seat a sample bullet to determine the cartridge overall length (C.O.A.L).
- The micrometer may now be adjusted to accomplish the desired C.O.A.L.

If you have any questions regarding the above procedures, please do not hesitate to contact our tech support members.

Email: [techline@redding-reloading.com](mailto:techline@redding-reloading.com)

Phone: (607) 753- 3331

### Lifetime Warranty Disclaimer:

***All Redding Reloading Equipment has been carefully inspected prior to shipment and is fully warranted to be free from defects in materials and workmanship for life.***

***Any product or parts which prove to be defective will be replaced or repaired without charge if returned prepaid to the factory.***

***Note: We reserve the right to decline responsibility where misuse or careless handling is evident or where repairs or modifications have been made or attempted by others.***

